


Fitting Instructions:

Tiger XC, Tiger XCA, Tiger XCx, Tiger 800XC, Tiger 800 XCx, Tiger 800 XCA A9708213

Thank you for choosing this Triumph genuine accessory kit. This accessory kit is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Completely read all of these instructions before commencing the installation of the accessory kit in order to become thoroughly familiar with the kit's features and the installation process.

These instructions should be considered a permanent part of your accessory kit, and should remain with it even if your accessory-equipped motorcycle is subsequently sold.



T0847

Parts Supplied:

1. Mudguard extension	1 off	2. Plastic rivet	4 off
-----------------------	-------	------------------	-------



Warning

The accessory kits covered in this instruction are designed for use on specific models of Triumph motorcycle. The accessory kits and the models applicable are listed at the start of the instruction. They should not be fitted to any other Triumph model or to any other manufacturer's motorcycle. Fitting an accessory kit to a Triumph model not listed, or to any other manufacturer's motorcycle will affect the performance, stability and handling of the motorcycle. This may affect the rider's ability to control the motorcycle and could cause an accident.



Warning

Always have Triumph approved parts, accessories and conversions fitted by a trained technician of an authorised Triumph dealer. The fitment of parts, accessories and conversions by a technician who is not of an authorised Triumph dealer may affect the handling, stability or other aspects of the motorcycle's operation which may result in loss of motorcycle control and an accident.



Warning

Throughout this operation, ensure that the motorcycle is stabilised and adequately supported to prevent risk of injury from the motorcycle falling.



Warning


A torque wrench of known accurate calibration must be used when fitting this accessory kit. Failure to tighten any of the fasteners to the correct torque specification may affect motorcycle performance, handling and stability. This may result in loss of motorcycle control and an accident.



Caution


When fitting the mudguard extension, ensure that the surfaces of the mudguard are protected from contact with other hard surfaces. Damage to the mudguard could result from inadequate care and/or protection during this process.

1. Remove the front mudguard as described in the Service Manual.
2. Position the mudguard extension to the inside of the front mudguard, taking care to ensure the moulded feature on the extension is positioned correctly to the lower edge of the mudguard.




1. Mudguard extension
2. Fixing holes

3. Using the holes in the mudguard extension as a guide, mark the position of the fixing holes on the front mudguard.
4. Remove the mudguard extension and drill four 5.5 mm diameter holes in the front mudguard at the positions marked in the previous step.



1. Front mudguard
2. Fixing holes

5. Reposition the mudguard extension to the front mudguard and using a suitable riveting tool, secure using the four plastic rivets provided in the kit. Ensure the male part of the rivet is to the outside of the mudguard as shown below.



cd0aa

- 1. Front mudguard**
2. Mudguard extension
3. Rivet

6. Refit the front mudguard as described in the Service Manual.
7. Ensure there is adequate clearance between the rivets, mudguard extension and the tyre when the mudguard is installed.



Warning

If, after fitment of this accessory kit, you have any doubt about the performance of any aspect of the motorcycle, contact an authorised Triumph dealer and do not ride the motorcycle until the authorised dealer has declared it fit for use. Riding a motorcycle when there is any doubt as to any aspect of the performance of the motorcycle may result in loss of control of the motorcycle leading to an accident.



Warning

Never ride an accessory equipped motorcycle at speeds above 80 mph (130 km/h).

The presence of accessories will cause changes in the stability and handling of the motorcycle. Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 80 mph (130 km/h) limit will be reduced by the fitting of non-approved accessories, incorrect loading, worn tyres, overall motorcycle condition and poor road or weather conditions.



Warning

The motorcycle must not be operated above the legal road speed limit except in closed-course conditions.



Warning

Only operate this Triumph motorcycle at high speed in closed-course on road competition or on closed-course racetracks. High-speed operation should only be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions.

High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.