


English

Fitting Instructions:
Thunderbird and Thunderbird Storm
A9758116, A9750510 or A9700366

Thank you for choosing this Triumph genuine accessory kit. This accessory kit is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Completely read all of these instructions before commencing the installation of the accessory kit in order to become thoroughly familiar with the kit's features and the installation process.

These instructions should be considered a permanent part of your accessory kit, and should remain with it even if your accessory equipped motorcycle is subsequently sold.



Parts Supplied A9758116, A9750510 or A9700366:

1. Lower mounting bracket	1 off	4. Upper mounting bracket, left hand	1 off
2. Upper mounting bracket, right hand	1 off	5. Nut	4 off
3. Carriage bolts	4 off	6. Bolt, M8 x 20 mm	4 off



Warning

This accessory kit is designed for use on Triumph Thunderbird and Thunderbird Storm motorcycles only and should not be fitted to any other Triumph model or to any other manufacturer's motorcycle. Fitting this accessory kit to any other Triumph model, or to any other manufacturer's motorcycle, may interfere with the rider and could affect the handling, stability or other aspects of the motorcycle's operation which may result in loss of motorcycle control and an accident.



Warning


Always have Triumph approved parts, accessories and conversions fitted by a trained technician of an authorised Triumph dealer. The fitment of parts, accessories and conversions by a technician who is not of an authorised Triumph dealer may affect the handling, stability or other aspects of the motorcycle's operation which may result in loss of motorcycle control and an accident.



Warning

Throughout this operation, ensure that the motorcycle is stabilised and adequately supported on a paddock stand to prevent risk of injury from the motorcycle falling.


1. Remove the upper bolt from the headlight mounting.
2. Loosen the lower bolt for the headlight mounting and lower the headlight.



1. Lower bolt
2. Upper bolt
3. Headlight

Note:

- **Note the position of the cable guide locating tang.**
- 3. Detach the two cable guides from the upper yoke. Retain the two screws if the motorcycle is to be returned to its original condition.




1. Cable guides
2. Screw
3. Locating tang

Note:

- **Before fitting this accessory kit, ensure the owner of the motorcycle has been informed of the warnings contained in these instructions.**

4. Fit the lower bracket to the lower yoke with the supplied M8 x 20 mm bolts. Do not fully tighten the bolts at this stage.




1. Lower mounting bracket

2. Lower yoke

3. Bolts

5. Align the left hand cable guide to the lower edge of the left hand upper mounting.
 6. Ensure that the cable guide locating tang aligns with the rear hole and fits the supplied M8 x 20 mm bolt through the front hole.

7. Fit the left hand upper mounting bracket and cable guide to the upper yoke. Ensure the locating guide is positioned as noted for removal. Do not fully tighten the bolt at this stage.




1. Left hand upper mounting

2. Left hand cable guide

3. Bolt

4. Upper yoke

8. Attach the left hand upper mounting bracket to the lower plate using two of the supplied carriage bolts and nuts. Do not fully tighten the nuts at this stage.




1. Left hand upper mounting

2. Left hand cable guide

3. Cable guide locating tang

4. Bolt




1. Carriage bolts

2. Left hand upper mounting

3. Lower mounting bracket


9. Repeat steps 5 to 8 to fit the right hand upper mounting.

10. Tighten the bolts for the lower mounting bracket to **26 Nm**. Left hand side shown.



1. Bolt

11. Tighten the bolts for the left hand and right hand upper mounting brackets to **26 Nm**. Left hand side shown.




1. Bolt

2. Upper bracket

Note:


- **Note the position of the split line for the front indicator clamp.**

12. To access the carriage bolt nuts, loosen the screw for the indicator clamp and push the indicator forward.




1. Front indicator clamp
2. Indicator clamp split line
3. Lower yoke clamp split line

13. Tighten the left and right hand carriage bolt nuts for the upper mounting brackets to **26 Nm**. Left hand side shown.




1. Carriage bolt nuts

14. Position the split line of the indicator clamp as previously noted and tighten the screw to **18 Nm**.



1. Front indicator clamp
2. Indicator clamp split line
3. Lower yoke clamp split line

15. Raise the headlight and fit the upper bolt. Do not fully tighten at this stage.




1. Lower bolt
2. Upper bolt
3. Headlight

16. Check the headlight alignment as described in the Service Manual.
 17. Tighten the headlight vertical alignment bolts to **9 Nm**.

Installing the Windscreen


1. Stand astride the front wheel and align the windscreens lower mounting slots to the lower mountings on the upper mounting brackets.



1. Lower mounting
2. Upper mounting
3. Windscreens upper mounting slot

Note:

- An audible click can be heard when the windscreens upper mountings are fully engaged.
- 2. Align the windscreens upper mounting slots to the mountings on the motorcycle. With a firm push, fully engage the upper mountings.




1. Upper mounting
2. Windscreens upper mounting slot

Removing the Windscreen

To remove the windspeed, carry out the following procedure.

1. Stand astride the front wheel and firmly grip both sides of the windspeed close to the upper mounting.



1. Upper mounting

2. Windspeed upper mounting slot

2. Pull the windspeed firmly to disengage the upper mountings. Then lift the windspeed up to disengage the lower mountings and completely remove from the motorcycle.



Warning

Never ride an accessory equipped motorcycle (including those fitted with Triumph approved windscreens and luggage systems) at speeds above 80 mph (130 km/h).

The presence of accessories such as windscreens and luggage systems will cause changes to the stability and handling of the motorcycle. Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 80 mph (130 km/h) limit will be reduced by the fitting of non-approved accessories, incorrect loading, worn tyres, overall motorcycle condition and poor road or weather conditions.



Warning

This motorcycle must not be operated above the legal road speed limit except in authorised closed-course conditions.



Warning

Never attempt to clean or adjust the windspeed while riding the motorcycle. Removal of the rider's hands from the handlebars while riding the motorcycle will diminish the ability of the rider to maintain the control of the motorcycle. Attempting to clean or adjust the windspeed while riding the motorcycle may result in loss of control of the motorcycle and an accident.



Warning

After fitting the windspeed mounting kit the motorcycle will exhibit new handling characteristics. Operate the motorcycle in a safe area free from traffic to gain familiarity with any new characteristics. Operation of the motorcycle when not familiar with any new handling characteristics may result in loss of motorcycle control and an accident.



Warning

If after the fitment of this accessory kit, you have any doubt about the performance of any aspect of the motorcycle, contact an authorised Triumph dealer and do not ride the motorcycle until the authorised dealer has declared it fit for use. Riding a motorcycle when there is any doubt as to any aspect of the performance of the motorcycle may result in loss of control of the motorcycle leading to an accident.



Warning

The windspeed is no substitute for a safety helmet or eye protection. Windscreens are designed to provide wind protection and increased rider comfort. They are not designed to provide protection in the event of a collision with another vehicle, the road, birds or any other objects. When riding a motorcycle, both rider and passenger must always wear a safety helmet, eye protection, gloves and trousers (close fitting around the knees and ankles). Although full protection is not possible, wearing correct protective clothing can reduce the risk of injury when riding.