

Fitting Instructions:

Rocket III, Rocket III Classic and Rocket III Touring Front Dresser Bar Kit - A9758049 and A9758099



Thank you for choosing this Triumph genuine accessory kit. This accessory kit is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Completely read all of these instructions before commencing the installation of the accessory kit in order to become thoroughly familiar with the kit's features and the installation process.

These instructions should be considered a permanent part of your accessory kit, and should remain with it even if your accessory equipped motorcycle is subsequently sold.




Warning

This accessory kit is designed for use on Triumph Rocket III, Rocket III Classic and Rocket III Touring motorcycles only and should not be fitted to any other Triumph model or to any other manufacturers motorcycle. Fitting this accessory kit to any other Triumph model, or to any other manufacturers motorcycle, may interfere with the rider and could affect the handling, stability or other aspects of the motorcycles operation which may result in loss of motorcycle control and an accident.



Warning

Always have Triumph approved parts, accessories and conversions fitted by a trained technician of an authorised Triumph dealer. The fitment of parts, accessories and conversions by a technician who is not of an authorised Triumph dealer may affect the handling, stability or other aspects of the motorcycles operation which may result in loss of motorcycle control and an accident.



Parts Supplied:

| | | | |
|-----------------------------------|-------|-----------------------|-------|
| 1. Dresser bar (left hand) | 1 off | 3. M8 x 25 bolts..... | 4 off |
| 2. Dresser bar (right hand) | 1 off | | |



Warning


Ensure that the motorcycle is stabilised and adequately supported to prevent it from falling and causing damage or injury.



Warning

A torque wrench of known accurate calibration must be used when fitting this accessory kit. Failure to tighten any of the fasteners to the correct torque specification may result in loss of motorcycle control and an accident.

1. Support the motorcycle on a paddock stand.
2. Support the weight of the motorcycle and engine such that front engine mounting bolt can be safely removed.
3. Remove the two lower M8 mounting bolts from the foot control rail on the left hand side of the motorcycle. Keep the displaced bolts in a safe place in case the dresser bars are ever removed.
4. Repeat on the right hand side of the motorcycle.
5. Remove the front upper engine mounting bolt and locknut.
6. Refer to the diagram below: Position the left hand dresser bar to the motorcycle as shown. Retain the bar at the lower locations with the two M8 bolts provided in the kit.
7. Repeat the mounting process on the right hand side of the motorcycle.
8. Refit the front upper engine mounting bolt, passing it through the dresser bar upper mounting points. Fit the lock nut and tighten to **80 Nm**.
9. Tighten the two lower mounting bolts to **27 Nm**.





Warning

After fitting the accessory kit the motorcycle will exhibit new handling characteristics. Operate the motorcycle in a safe area free from traffic to gain familiarity with any new characteristics. Operation of the motorcycle when not familiar with any new handling characteristics may result in loss of motorcycle control and an accident.



Warning

If, after fitment of this accessory kit, you have any doubt about the performance of any aspect of the motorcycle, contact an authorised Triumph dealer and do not ride the motorcycle until the authorised dealer has declared it fit for use. Riding a motorcycle when there is any doubt as to any aspect of the performance of the motorcycle may result in loss of control of the motorcycle leading to an accident.



Warning

Never ride an accessory equipped motorcycle (including those fitted with Triumph approved windscreens and luggage systems) at speeds above 80 mph (130 km/h).

The presence of accessories such as windscreens and luggage systems will cause changes in the stability and handling of the motorcycle. Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 80 mph (130 km/h) limit will be reduced by the fitting of non-approved accessories, incorrect loading, worn tyres, overall motorcycle condition and poor road or weather conditions.



Warning

The motorcycle must not be operated above the legal road speed limit except in closed course conditions.



Warning

Only operate this Triumph motorcycle at high speed in closed-course on road competition or on closed course racetracks. High speed operation should only be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions.

High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.